

INDEX

FOREWORD.....	1
CHAPTER 1 GENERAL INFORMATION	2
1.1 MACHINE USAGE.....	2
1.2 TECHNICAL DATA	2
1.3 SAFE OPERATION RULES.....	4
CHAPTER 2 HANDLING AND INSTALLATION.....	8
2.1 HANDLING	8
2.2 PREPARE THE SITE.....	8
2.3 MACHINE LEVEL ADJUSTMENT.....	9
2.4 FIXATION OF EXPANSION BOLTS.....	10
2.5 REMOVAL OF FIXING PLATES	11
2.6 CLAMPS SPACE ADJUSTMENT.....	11
2.7 INSTALLATION OF COVERS.....	14
2.8 RIGHT-ANGLE MILLING HEAD TEST	19
2.9 AIR SOURCE AND AIR PRESSURE	21
2.10 TOOLS INSTALLATION.....	24
2.11 DUST EXTRACTION EQUIPMENT.....	30
2.12 OPERATION AREA AND SAFETY ATTENTIONS.....	31
CHAPTER 3 MAINTENANCE	32
3.1 MACHINE MAINTENANCE	32
3.2 LUBRICATION	33
3.3 MAINTENANCE OF SPINDLE AND TOOL HANDLE	38
3.4 OTHER MAINTENANCE	39
3.5 HOW TO CHANGE SERVO BATTERY	39
CHAPTER 4 PNEUMATIC CIRCUIT DIAGRAM	40
CHAPTER 5 ELECTRICAL CIRCUIT DIAGRAM	42

FOREWORD

Our CNC boring machine is under constant development. The equipment provided to you may not match the description in this manual, which just gives a general description of machine and can't be the credentials of equipment acceptance. Please note the following items before starting this machine.

- It is suggested that all the staff members related to the machine should read this manual book.
- The operator of the machine should be trained on the relevant technology or instructed by a special person.
- This manual introduces the performance, structural characteristics and operation of the machine.
- The manual reminds users of the safety precautions and typical methods of operation. Observance to the methods of operation can avoid the occurrence of accidents, reduce downtime and maintenance costs, so as to improve the utilization rate of machine and production efficiency.
- This manual book describes the items related to work injury prevention and environmental protection, etc. Users can supplement according to the specific circumstances of their country.
- This manual shall be placed near the machine, allowing easy access for the operator and the relevant maintenance personnel.
- In addition to the manual and the rules of accident prevention in the user countries, the operator must comply with the recognized reasonable safety operation standards.

Safe signs:

 DANGER Strike danger Do not close when running	Stay away from this location to avoid crushing and shearing caused by strong force.
	Do not open the electric cabinet or touch anything with electricity to prevent electric shock.
	Watch your hands when machine is running.
	Be careful not to get injured when machine is running.
 WARNING Clamping danger Do not close when running	Stay away from this location to avoid injury caused by strong force.


Chapter 1 General Information

1.1 Machine Usage

This is an NC machining equipment featured in simple operation, high efficiency and high , with which to perform drilling, widely applied to all kinds of panel furniture .Machine was designed to operate on wood and similar materials. Metals are strictly excluded.

1.2 Technical Data

● 1.2.1 Plane dimension



1.2.2 Technical parameters

Model	610Z/610HZ
Panel length	70~2800mm
Panel width	50~1000 mm 35~50mm ($L \leq 1000\text{mm}$)
Panel thickness	9~60mm
Max motion speed of clamps	140m/min
Max speed of Y axis	90m/min
Max speed of Z axis	50m/min
Max speed of B axis	75m/min
Max speed of C axis	30m/min
Number of tools	Upper drill: 12(V)+8(H) Bottom drill: 9(V)
Drill chuck spec.	Φ 10
Spec. for upper-spindle tool handle	ISO30-ER32
Dust Connections	Φ 200mm*1 Φ 100mm*1
Overall size	5270L*2660W*2190H mm
Total power	21. 9kW
Working pressure	0. 6 MPa


1.3 Safe Operation Rules

Warning: Please carefully read the corresponding safety rules before operation and operate the machine in strict accordance with the safety regulations. If any doubt, please do not operate the machine without authorization, please contact the nearest dealer or machine manufacturer for help.

1.3.1 Safe operation rules:

- (1) Specify professional operators;
- (2) Prohibited to put mess on the working table;
- (3) Before enabling the machine, please ensure there are no extra operators or mess around it;
- (4) It is very important to wear safety helmet and goggles. Gloves are not necessary to operate the machine.
- (5) Keep machine and worktable surroundings clean and tidy;
- (6) When abnormal alarm signal occurs, the operator should immediately stop all processing and timely solve the problem, until the problem is solved before operating the machine again.

	During machine processing, the door must be closed to avoid improper operation and injury resulting from the collapse of knife or sawtooth flying out!
------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------




1.3.2 Safe operation rules for changing tools:

Please confirm the following items before changing tools

A Machine stops running;

B Press down an EMG stop button to lock machine.


C Fix the collet in the tool holder, place the cutter in the tool holder and confirm to secure the tool lock.




The tool installation length L shall not be greater than the distance K from the end face of the tool handle to the bakelite of the plate. L=40mm is recommended


1.3.3 Safety operation rules for tool magazine

(1) Tool magazine in upper spindle has five positions. Under the situation of spindle has a cutter, at most four cutters can be placed in it, which can be chosen from vertical milling cutter, vertical Lamello milling cutter, horizontal Lamello saw blade, horizontal saw blade, etc. Cutters of other specifications can also be added in the tool magazine, then fill in the relevant size information and keep the size information accurate, otherwise the plate and machine may be damaged.





(2) If changing the tool manually is needed, switch to manual mode, move the spindle mechanism to the right side (pay attention to adjusting the spindle height and avoiding tool magazine). After confirming the spindle is not rotating, hold the knife holder by hand, and then press the button next to the tool magazine to relieve the knife.




Chapter 2 Handling and Installation

2.1 Handling

Handling with forklift

Machine should be lifted by means of forklift, lifter arm inserts into to machine bottom, put some appropriate packing material on the gravity center, so as to protect machine from damage.

First, lift up one side by the forklift, place a wood block under, then lift up the whole machine. slowly and with the utmost care while preventing oscillations as much as possible.



2.2 Prepare the Site

This machine is a CNC equipment with high precision and electromechanical integration, in order to avoid precision error due to abnormal vibration in the process of operation, the installation site should meet the following requirements:


- The floor must be concrete with the thickness no less than 20cm and the bearing capacity should be greater than machine weight (about 4000kg).
- The machine should be installed at a place free from vibration, collision and shock, and be far away from the vibration source.
- The machine should be installed at a place free from rain. Installation in the open air is prohibited. to ensure running in correct environment so as not to damage the internal parts of the machine.
- To ensure correct use and maintenance operations in safe conditions, there must be enough operation space reserved in the factory site, and ensure there must be at least 2 meters away between machines or walls around. If necessary, it is recommended to delimitate an area marked by a yellow line on the floor, which must be kept clean and unobstructed around machine.

2.3 Machine Level adjustment


Adjust machine to be leveled:

Place the leveler in mid-worktable. Placement point of the leveler is at the vertical and horizontal positions in both ends of mid-worktable (see below figure), and adjust machine to be levelled by the Anchor Bolt

After machine is levelled, place the leveler at both ends of the clamp stroke to check if machine is in level; if not, please make slight adjustment.




Adjust machine be levelled by anchor bolts



2.4 Fixation of expansion bolts

After the machine is adjusted horizontally, fix the base anchor on the mounting surface with expansion bolts. You are advised to use M16 * 200 expansion bolts for anchor bolts. Position N shown in the following picture is the place to fix expansion bolts.

It is recommended that M10*120 expansion bolts be used to fix the two supporting baseplates of each safety fence on the installation surface. To ensure the safety of the rear area when the machine is working, secure the safety fence according to the position shown in the figure.




Expansion bolts for main frame

2.5 Removal of Fixing Plates

To prevent moving of drill unit, clamps, and side aligner along the clamp stroke when handling and transporting, they were fixed in the factory with plates as below images shown. After the installation completed, please dismantle the fastening plates.

Open the machine's safety guards and find the identify fastening plates shown in below pictures.




2.6 Clamps Space Adjustment

According to the thickness of workpiece, the open space of clamps could be adjusted by regulating screw underneath. And the adjust range is 36-66mm. Decrease of the open space can improve drilling efficiency.

Please be noted that the open space shall be 6mm greater than thickness of the workpiece, or there would be errors in out-feeding.

As shown in the following figure, there are 3 sets of adjusting screws in the clamps (Clamp X and A are the same). The adjusting screw 1 is used to adjust the upper limit of bottom clamp, and the adjusting screw 2 is used to adjust the lower limit of bottom clamp, while the adjusting screw 3 is used to adjust the upper limit of upper clamp, that is, the maximum open space of clamps.



- A. Adjusting screw 1: Used to adjust the upper limit of bottom clamp
- B. Adjusting screw 3: Used to adjust the upper limit of upper clamp(Max. space of clamps)
- C. Magnetic switch
- D Adjusting screw 2: Used to adjust the lower limit of bottom clamp
- E. Block underneath clamp

Specific adjustment steps and matters to be attention are as follows:

- (1) When clamps close: screw off nut 1 to move bottom clamps downwards or upwards to an appropriate position, then screw up nut 1. At this moment, position of the bottom clamp is the upper limit of bottom clamp in close state. In this position, surface of bottom clamp should be about 0.1mm higher than the that of worktable, so as to prevent friction between workpiece and worktable during the movement,
- (2) When clamps open: screw off nut 2, to move bottom clamps downwards or upwards to an appropriate position, then screw up nut 2. At this moment, position of the bottom clamp is the lower limit of bottom clamp in open state. In this position, surface of bottom clamp should be about 0.5mm higher than the that of worktable, so as to prevent collision with bottom clamp plates when workpiece is conveying transversely
- (3) The open space of clamp is set to be 36mm in the factory, and the maximum space can adjust to be 66mm which can satisfy machining with 60mm workpiece. In practice application, the maximum spacing could be adjusted according to maximum thickness required in order to reduce the clamping time and further improve the machine's efficiency.

As it is a big adjustment, it is suggested to screw up the nut 3 when clamp cylinder

is empty of compressed air., by this moment, nut 3 is against the upper parts, move the upper clamp downwards till it reaches the required open space, then screw up nut 3 to lock.



If it is once again to enlarge the open space, screw off nut 3 to an appropriate position and lock again. At the same time, please adjust position of the magnetic switch ensure the magnetic switch can sense position of cylinder rod when the upper clamp lifts up in place.

Attention: When adjusting the position of the magnetic switch, pay attention to moderate strength so as to prevent damage to the head of the screw, which would cause screw loose.

- (4) Use the blunt end screw of M8*55 for adjusting screw, the screw that is longer than 55mm is not allowed. Otherwise, it would cause collision between parts and make the machine damaged. After adjustment, these two screws must contact the limit block at the same time, then lock the nut
- (5) When adjusting the space to be 36mm -46mm, the locking nut should be above the bottom block underneath clamp. When adjusting to be 46mm-66mm, the locking nut should be locked under the bottom block, finally adjust the height of glass.

2.7 Installation of Covers


Before the machine is packed and transported, remove the right cover, left cover, front cover, front gripper guiderail cover, front towline cover, hanging board and fence first.



Above figure indicates:


- (1) Fence; (2) Front gripper guiderail cover; (3) Front cover; (4) Right cover; (5) Front towline cover; (6) Left cover
(7) Hanging board 1; (8) Hanging board 2; (9) Hanging board 3

2.7.1 Installation Diagram of Right side cover




1. Connect the right cover and column with long angle iron
2. Connect the right cover and machine frame with small angle iron
3. Connect the right cover and supporting column with long angle iron

2.7.2 Installation Diagram of Left side cover




1. Connect left-side cover with left column of front cover by angle iron;
2. Connect left-side cover with main electric cabinet.

2.7.3 Installation Diagram of rail cover in front



- 1 Connect the front towline cover and gripper guiderail with connector
2. Connect the front gripper guiderail cover and column
3. Connect the front gripper guiderail cover and left cover with connector

2.7.4 Installation Diagram of rail cover in front:


As (1) & (2) marked above are the mounting holes for front cover

2.8 Right-angle milling head test


The right-angle head of the spindle is optional. If it is installed or replaced for the first time, please install and test according to the following way.

Install the right-angle milling head on the spindle as picture shows.


Note: The positioning pin of the right-angle head should be inserted into the positioning waist hole, where the positioning flange is away from the drill bag.



(2) Gently shake the right-angle head from left to right, which can be realized if there is a gap. To ensure the right-angle head not shake left to right, slightly loosen the lock nut on both sides and adjust the machine, and enable the right-angle head positioning pin rise to insert the flange slot under the action of internal spring.



(3) Install the milling cutter on both sides of the right-angle head, with tool handle partially outside the tool holder. Use a dial gauge to measure the parameter of milling cutter handle on both sides, loosen the locking screws of right-angle head index plate, and fine-adjust the angle of right-angle head to ensure that milling cutters on both sides are parallel to Y axis of the machine. After adjustment, use torque wrench to lock the right-angle head screw, and then check the meter to ensure accuracy.




2.9 Air Source and Air Pressure

A drying equipment must be installed to avoid mechanical faults caused by excessive moisture content in air tank. Make sure the air pressure is 6kgf /m² or above (specified pressure value in pressure gauge for air filter). If there are changes in the air pressure, adjust the pressure regulator to maintain the air pressure within a certain range, check in every 7 working days

Air pipe diameter is 16mm. The tip diameter must be or more than 1 inch, otherwise the pressure will be insufficient.


Notes:

- 1、Compressed air discharged by the air compressor could not be used directly, because it contains a certain amount of water, oil and dirt. The air temperature after compressed is up to 140 ~ 170 °C, with part of the water and oil transformed into gas, therefore, it must apply the dried and cooled gas as the air source.
- 2、There is a part of water vapor in the air storage tank, which is not completely dried in the air source and liquefied at the bottom of the air storage tank. It is necessary to open the ball valve every day to drain water from the air storage tank. Ball valve is situated below left beam.



3. When applying oil to the oil lubricator, screw off oil plug and apply oil up to 80% level. Please check and lubricate periodically and have machine run in sufficient oil.
4. Keep the oil level between the upper and lower limits, and make sure for timely application
5. Do not stop oil applying in a work cycle. Otherwise, the related parts will be worn more quickly and run poorly due to lack of lubrication

6. Air source filter and Valve terminal in drill unit are automatic drainage device. When the liquid level reaches the warning line, they will automatically drain without manpower



Adjust the pressure regulator to make the indicated value to be proper one. For users' convenience, there are five pressure regulators in the machine, including pressure regulator in left spindle pressing plate, pressure regulator in right spindle pressing plate, pressure regulator in gripper cylinder, pressure regulator in upper drill head pinch roller and pressure regulator in spindle air block.

Under normal circumstances, the pressure regulator for side aligner should be adjusted to 0.2MPa,


If too much pressure on panel, it would make panel move uneasily.

The regulator for clamps shall be adjusted to a appropriate value according to material of workpiece. Too much pressure would cause damage on panel surface.

Under normal circumstances, the pressure regulator for left and right pressure plates on spindle should be adjusted to 0.2MPa to ensure proper pressing force when milling.

Under normal circumstances, the pressure regulator for pressure roller on bottom drill should be adjusted to 0.2MPa to ensure proper pressing force when drilling.

Under normal circumstances, the pressure of the spindle air-block regulator should be adjusted to 0.2~0.3mpa to ensure the formation of air curtain at the bottom of the spindle to prevent dust from entering.



The above figure indicates:

1. Pressure regulator in drill head pinch roller
2. Air-block regulator in spindle
3. Pressure regulator in left and right spindle pressing plate
4. Pressure regulator in gripper

2.10 Tools Installation

A、Spindle tools installation


- It is suggest to use a tool holder with diameter of 1/2 inch on spindle, Tools length range is 70mm while tool diameter range is 1-16mm.
- The max. diameter of saw blade in upper spindle should be 100mm.
- The actual drilling range in Y direction of spindle in lower drill head should be 0~980mm;
- The length of tools inserted to collet shall be twice greater than diameter of holder, which would be better for fastening.
- The length of tools that stretched out of collet shall be measured and write into the software as tools length setting.



Note: Installation not complied with above requirements may cause damage to machine and injury to workers .

B、Installation and use of spindle right-angle milling head

- The total lengths of tools on both sides of the right-angle milling head shall not exceed 80mm, otherwise there is a risk of damage gripper guid rail.
- After continuous working, the right-angle milling head, as a precision component, must be stopped for a certain time before processing again. Otherwise, it may be damaged because of high temperature. Rest time for right-angle milling head can refer to the figure below.




C、Installation of air drill


- Drill head spec.: The drill head handle must be 10mm in diameter and 70mm in length, with all drill head must in the same length.

- Apply lubrication grease on the drill head handle when mounting drill head, in case of difficult removal because of rust.
- The drill head must be fixed with M6*6 flat-end hexagon socket, which must be removed from the tool position where drill head is not installed.
- Drill of different sizes must be installed in accordance with the requirements of the following figure to avoid machine damage;

Tool magazine is recommended to set as follows:



- In the figure above, the positions of no. 1-11 are only available to install drill bits with diameter no more than 20mm.
- No 1-5 positions in above figure are available for through hole drill while it is not available in no. 6-12 positions in order to avoid hit against with the worktable and make damage on table.
- In the figure above, the positions of no.13-20 are only available to install drill bits with diameter no more than 16mm.
- In the figure above, position of no.12 is available to install drill bits with diameter no more than 35mm. The drill bit with diameter of 35mm features in two-edged which is for better drilling quality.
- When through hole is required, it is recommended to apply drills no.1-5 working with bottom drills. If the through hole indeed needs to be done by upper drills, install through-hole drills at position of No. 1- 5 positions, then reduce the feed speed of drills and select drill bits with good quality, but to a certain extent, there are also risk in poor drilling
- The layout of tools can be adjusted according to the required machining. And no.5-12 drill bits are commonly used for best drilling effect.



- In the figure above, the positions of no. 1-11 are only allowed to install drill bits with diameter no more than 20mm.
- No 1-5 positions in above figure are available for through hole drill.a through hole drill is not allowed in no. 6-12 positions to avoid the worktable from rupture
- In the figure above, the positions of no.13-20 are only allowed to install drill bits with diameter no more than 16mm.
There is no need to install drill bits at No 15 and 16 positions.
- In the figure above, the no.12 position allows a drill bit with diameter no more than 35mm. The drill bit with diameter of 35mm is two-edged and can result in better processing quality.
- When through hole is required, it is recommended to drill through at No 1-5 positions combining top drill unit with bottom one. If the through hole indeed needs to be done by top drill head, install throughhole drills at No 15 positions, then reduce the feed speed of drill and
select drill bits of the best quality. But to some degree, the risk of poor processing is inevitable in doing so.
- The layout of tools can be adjusted according to the processing technology. And no.5-12 drill bits are commonly used for their best processing effect.

610Z/610HZ bottom drills layout

Bottom drill head

red (7)	black (8)	red (9)
Ø5	Ø15	Ø5
black (4)	red (5)	black (6)
Ø10	Ø8	Ø15
red (1)	black (2)	red (3)
Ø8	Ø10	Ø5

- As figure shows above, No. 1~4 and No. 6~9 position in lower drill can only install drill head with diameter equal or greater than 20mm;
- No. 5 position in lower drill can only install drill head with diameter equal or greater than 35mm;
- Drilling distance of drill head in No. 3, No. 6 and No. 9 position in Y direction is equal or greater than 32mm;




Please install according to above suggestion, otherwise, machine damage and personnel injury might be caused.

Note: it is recommended to use double-edged bits with diameter of 35mm for a better drilling quality.

Double-edged drill bit with diameter of 35mm is shown as below:



D、Installation of saw blade

The above figures indicate:

- (1) Side dust extraction cover
- (2) Screw nuts for mounting saw blade

Saw Blade Installation Instruction


- (1) Nuts dismounted: Prepare an 8mm inner hex spanner and a 31mm open-end wrench or monkey wrench, insert the 8mm inner hex spanner into the hexagonal hole in saw shaft, then lock the nut with the open-end wrench and rotate as the arrow indicates to loosen the nut.



- (2) Saw plate thickness: The min lockable thickness of saw plate is 1.5mm and max lockable thickness is 5mm.



(3) Rotation direction of saw blade: The cutting direction of blade teeth should be the same as the arrow indicates on the nut of saw shaft (screw up the nuts after confirmation).



Notes:

1. Please Confirm the rotation direction before installing saw blade. (Motor must go forwards), because Wrong direction will cause the nut loose and further to cause injury to personnel.
2. Diameter of saw blade is 120mm, width limit of blade tooth is 6mm. (Suggest to use blade with 24 teeth or more)
3. Please adjust the feed depth and feed speed respectively according to different wood material
4. When grooving with blade, working size in Y axis should be less than 1000mm (for model 610HZ)
5. Grooving depth with blade should be less than 15mm



Please install according to above suggestion, otherwise, machine damage and personnel injury might be caused.

2.11 Dust Extraction Equipment

It is suggested to equip dust extraction in the factory to ensure for a clean working environment and good performance on machine:

- (1) Prepare some dust suction pipe with proper specification referred to the machine layout, and connect the pipes from dust extraction equipment to installation position of the machine
- (2) Make sure a well connecting between the pipe orifice, so as to prevent air leakage from the suction inlet
- (3) It is suggest to keep the wind blowing speed above 30m/s



Note: If the connecting pipe is too long, it would cause the drop part damaged after machine starts. Therefore, it is necessary to consider if there is supporting bracket needed in the pipe installation and pipe length, so as to maintain a best dust suction effect.

2.12 Operation Area and Safety Attentions




The operating area is the zone in which the personnel assigned to the system are expected to work.

In the layout of operating area, the symbol refers not only to the area where the programmer is located but also the areas where machine adjustments and operations are expected to be conducted, meanwhile, keep personnel off the areas marked in dotted line when the machine is running.

Before starting up the machine, Operator shall check if machine parts are in good condition, close all safety covers and make sure there is no other staff or debris around machine.

When Machine is running, Operator shall not leave the machine without permission, and should pay attention to the running status. If there is any abnormality or incident occurs, stop the machine immediately

Before machine stop running, all personnel around the machine should stand beyond the dotted line area, and take away the workpiece only when machining completes and machine stops running



Do not permit unauthorized personnel to approach the machine during operation.



Operating areas must be well illuminated.

Chapter 3 Maintenance

3.1 Machine Maintenance

- (1) Do not modify the machine without authorization before completely understanding the performance of machine to avoid fault or damage to the machine;
- (2) Power off the machine before carrying out any maintenance;
- (3) Be sure that the front cover and right door are locked before powering on the machine after maintenance;
- (4) Periodically check if the EMG stop buttons are intact;
- (5) Record the repaired or replaced abrasive parts.

3.2 Lubrication


(1) ISO VG 46 mechanical lubrication grease should be applied to intermediate electric thin-oil pump, and grease amount should be applied to 3/4 when it's below 1/4.




(2) Add 0# mechanical grease to manual oil pump, shake the rocker 3 to 5 times every day before working.



(3) Linear slide is a precision moving part which requires good lubrication in order to ensure its service life. Some sliders are connected with oil pipe supplied with oil by the electric oil pump. The other sliders unconnected with tubing should be lubricated with 0 # machinery grease by a manual grease gun once a week.




(1)(2)(3) Manual grease application in gripper upper slider



Manual grease application in upper spindle slider

Manual grease application in lower spindle slider



Manual grease application in tool magazine slider

Manual grease application in assistant worktable slider

Please equip with large-flow manual oil-application gun



(4) Drill head maintenance

Gear lubrication

Periodically apply oil through the nozzle to gear box of the of drill head (indicated as below picture).

- (1) Safety precaution: shutdown and power off to avoid human injury caused by unexpected operation.
- (2) Lubrication cycle: suggested to apply grease after every 40-120 working hours.
- (3) Grease type: requires application with ISOFLEX TOPAS L 32 N
- (4) Application amount: 0.3-0.5g per shaft. Please do not apply too much grease on drill head, to prevent high temperature caused by load increase.
- (5) Application amount to horizontal drill holder: 2g grease every half year is suggested.
- (6) Application method: rotate the drill spindle manually while applying grease and have the grease spread to every gear.


Cylinder maintenance

Periodically check if there is water left in the air filter and if there is oil left in the lubricator.

Drill spindle maintenance

- a. Suggested to do cleaning every 5-7 days.
- b Blow off the dust on the spindle and dust cover with a pneumatic gun.
- c Stretch out all vertical and horizontal spindles, spray some anti-rust oil on a clean cloth and wipe every spindle (be sure to wipe them clean), then drizzle another clean cloth with rust-proof oil and wipe every spindle. (It is suggested to wear gloves in the clean process. Directly doing with the hand is prohibited.)
- d Start the built-in heating program to let the spindles stretch out and draw back for about 2 minutes.


e.The built-in heating program must be run at least once (3-5 minutes) after machine starts every day.



(5) The components in pneumatic circuit requires to be lubricated by oil lubricator.

If. there is insufficient oil in the lubricator, please apply 32# anti-wear hydraulic oil.

The side aligning unit, slider and screw rod in bottom drilling unit are lubricated by oil lubricator and oil amount can be adjusted by the throttle valve at exist of lubricator (Only six-sided drill model has the mist lubricator for slider of bottom drill), when there is insufficient oil, please apply with ISO VG 46 mechanical lubricants.





Attention: Please apply oil timely to the lubricator when there is insufficient oil. And should be operated according to indications on taps on lubricator.

(6) Maintenance of gears&racks




Gears&Racks, as the important transmission part in the machine, is required to make periodical maintenance and repair.

- a) Before maintenance, please clean dust off the gears with a pneumatic gun, and then wipe with a clean cloth.
- b) Each 3 days as a maintenance cycle, use a clean brush to apply an appropriate amount mechanical oil (Model: ISO VG 46) on the gear surface, and have the machine run back and forth several times to lubricate evenly
- c) Finally, wipe off the excessive oil left on the gears with a dry and clean cloth so as to prevent dust/chips stick on.

3.3 Maintenance of spindle and tool handle

(1) Before using electric spindle every day, ensure that the conical surface of both tool handle and electric spindle gripper are completely clean. After working each day, clean these parts with a clean cloth.

(2) When there is no tool handle, it is forbidden to feed compressed air into the spindle.



(3) Once every two weeks, use a clean soft cloth dipped in ethanol to carefully clean the conical surface of the handle (including the right-angle milling head). After cleaning, spray anti-rust agent KLUBER LUSIN PROTECT G31 on the conical surface of the handle, and apply it evenly with a dry cloth.


3.4 Other Maintenance

- Regularly clean the operation panel to avoid dusts and chips stuck in buttons, which may cause poor contact.
- Regularly clean the wood chips and dust on the linear guide, keep clean to ensure smoothly movement of the machine.
- In order to maintain the normal working of cooling system, please clean up the cooling fan filter once a week (The electrical box under master table and that behind machine are both equipped with a fan).
- Clean the intake filter of high pressure blower once a week, blow and clean with pneumatic gun after disassembly and then mounted back.


3.5 How to Change Servo Battery

The absolute value servo system is applied to the machine, which is powered by battery and can record the servo pulse position. But the servo battery has a certain service life. When servo driver shows error AL061 which means low battery. Or when checking the battery by setting P0-02 as 38, if it shows 31, which indicates that battery voltage is less than 3.1V, to avoid origin data missing, please change battery immediately. If battery voltage is less than 2.7V, it has caused the data of servo pulse position missing, please replace the battery with a new one and reset origin position. **Dry battery power voltage must be 3.6V, and factory battery is recommended.**


Note: Suggest to change battery when servo is power on to avoid absolute value of servo position missing.




Chapter 4 Pneumatic Circuit Diagram





610HZ Pneumatic Circuit Diagram





Chapter 5 Electrical Circuit Diagram





















































































































Welding drawing of upper left drilling bits

20 core cable

Y09	17	1	Y00
Y0A	18	2	Y01
Y0B	19	3	Y02
Y0C	20	4	Y03
Y0D	21	5	Y04
Y0E	22	6	Y05
Y0F	23	7	Y06
Y10	24	8	Y07
Y12	25	9	Y08




terminal no.	color of wire	terminal no.	color of wire
1	black	20	red&blue
2	orange	21	gray&brown
3	yellow	22	gray&pink
4	green	23	white&yellow
5	purple	24	white&green
6	red	25	pink&brown
7	gray	33	
8	white	34	blue
9	white&pink	35	
17	pink	36	white&gray
18	brown&green	37	
19	yellow&brown		

Design Check	Date ***	Date ***	Picture name Project	Upper left drilling 610(H)Z	Design department	CNC R&D center	Ver. 1.1
1	2	3	4	5	6	7	8

Guangzhou KDT Machinery Co., Ltd.

Page:

41



A		B		C		D		E		F	
1	2	3	4	5	6	7	8	9	10	11	12
Servo CN1											
Servo CN1 soldering table											
Server Driver CN1											
D	Remark	PIN	description	X-axis	A-axis	Y-axis	Z-axis	B-axis	C-axis	U-axis	color
Emergency	COM+	2	COM+ for input	+24V1	+24V1	+24V1	+24V1	+24V1	+24V1	+24V1	red
brake+	3	Port D01+ output	KAE01-2	KAE01-2	KAE01-2	KAE01-2	KAE01-2	KAE01-2	KAE01-2	KAE01-2	black
brake-	4	Port D01- output					+24V1	+24V1			red
COM-	12	COM- for output					KAZ	KAB			brown
							24G	24G			blue
6*0.3 shielded cable											
Guangzhou KDT Machinery Co., Ltd.			Design	*****	Date	*****	Picture name	CN1 of servo driver B3	Design department	CNC R&D center	Ver. 1.1
Check			*****	Date	*****	Project	610(H)Z	Total:	46	Page:	43
1	2	3	4	5	6	7	8				

A	1	2	3	4	5	6
B					7	8
C						
D						
E						
F						

Servo drive and motor power welding diagram for X, A, B, C, U axis

Servo Driver	Describe	Servo Motor	Color
5 (brown)	Motor U phase	4	brown
6 (black)	Motor V phase	3	black
7 (blue)	Motor W phase	1	blue
Ground	Motor ground	2	yellow/green

Servo motor connector

Servo drive and motor power welding diagram for Y, Z axis

Servo Driver	Describe	Servo Motor	Colour
5 (black1)	Motor U phase	2 (B)	black1
6 (black2)	Motor V phase	3 (C)	black2
7 (black3)	Motor W phase	4 (D)	black3
ground	Motor ground	1(A)	yellow/green

W and Z servo drives implication

	Servo motor	color
Brake signal 1	1 (+24V)	brown
Brake signal 2	2 (24G)	blue
Brake signal 3		

W-axis and Z-axis servo brake joints

Guangzhou KDT Machinery Co., Ltd.

Design	Date	Picture name	Design department	CNC R&D center	Ver.
Check	*****	Project	610(H)Z	Total:	1.1
1	2	3	4	5	7
					8

Page: 45

